

Cleaner S



Degreases and cleans all metals, glass, ceramics and most plastics

WEICON Cleaner S removes oily and greasy soiling from all metals as well as from ceramics, glass and most plastics. It can, however, attack the surface of thermoplastics such as PVC, Plexiglas, polystyrene and single layers of paint. WEICON Cleaner S evaporates quickly and, in contrast to conventional thinners, without leaving residues. It can be used for cleaning and degreasing before priming and painting, for cleaning machine parts, or before other WEICON products are applied to surfaces where a greasy underground would impair their effect.

Characteristics

| | |
|------------------------------|---|
| Specific properties | evaporates without residues |
| Colour | colourless, transparent |
| Odour | Orange |
| Shelf life | 24 mon. |
| suitable for processing with | WSD 400 WPS 1500-V Pump Dispenser Special |

Chemische Kennwerte

| | |
|----------|-----|
| AOX-free | yes |
|----------|-----|

Approvals / Guidelines

| | |
|-----------|-----------------|
| ISSA Code | 53.402.53/54/55 |
| IMPA Code | 551571/72/73 |

Processing

Dip in part to be cleaned, or brush or spray on Surface Cleaner sufficiently (e.g. with an Air Pressure Can). Use a clean cloth or nonwoven fabric to wipe off wet residues making sure that impurity and solvent remainders are removed. Repeat the cleaning process if necessary. Let the solvents evaporate until the surfaces have dried.

Storage

Store in tightly closed original container. Protect from direct sunlight. The storage temperature must not exceed +50°C. Keep container in a cool, well-ventilated location. Store in dry place.

Instructions for use

When using WEICON products, the physical, safety-related, toxicological and ecological data and regulations in our EC safety data sheets (www.weicon.com) must be observed.

Accessories

| | |
|----------|--|
| 1000393 | Adapter for WSD 400, 1 PCE |
| 10009303 | Spray Set for WSD 400, 1 PCE |
| 10009301 | WSD 400 Pressurized-Air Spray Can, 1 PCE |
| 10000398 | Adjusting Valve for cans, 1 PCE |
| 10016002 | Pump Dispenser WPS 1500, 1 PCE |
| 10016213 | Extension tube for WPS 1500, 1 PCE |
| 10000402 | WEICON Pump Dispenser Special, 1 PCE |

Available sizes

To the product detail page:



Note

The specifications and recommendations given in this technical data sheet must not be seen as guaranteed product characteristics. They are based on our laboratory tests and on practical experience. Since individual application conditions are beyond our knowledge, control and responsibility, this information is provided without any obligation. We do guarantee the continuously high quality of our products. However, own adequate laboratory and practical tests to find out if the product in question meets the requested properties are recommended. A claim cannot be derived from them. The user bears the only responsibility for non-appropriate or other than specified applications.

WEICON Middle East L.L.C.
United Arab Emirates
phone +971 4 880 25 05
info@weicon.ae

WEICON Czech Republic s.r.o.
Czech Republic
phone +42 (0) 417 533 013
info@weicon.cz

WEICON GmbH & Co. KG
(Headquarters) Germany
phone +49 (0) 251 9322 0
info@weicon.de

WEICON Romania SRL
Romania
phone +40 (0) 3 65 730 763
office@weicon.com

WEICON South East Asia Pte Ltd
Singapore
Phone (+65) 6710 7671
info@weicon.com.sg

WEICON Inc.
Canada
phone +1 877 620 8889
info@weicon.ca

WEICON Ibérica S.L.
Spain
phone +34 (0) 914 7997 34
info@weicon.es

WEICON Italia S.r.l.
Italy
phone +39 (0) 010 2924 871
info@weicon.it

WEICON SA (Pty) Ltd
South Africa
phone +27 (0) 21 709 0088
info@weicon.co.za

WEICON Kimya Sanayi Tic. Ltd. Şti.
Turkey
phone +90 (0) 212 465 33 65
info@weicon.com.tr